




Add your Food Grounds to your garden or curbside compost, share them with a local farm partner, or send them to Mill and we'll get them back to a farm.



How it all works

Setting up your bin is easy — and using it is almost effortless.



Assemble your bin

1

FIND A FLAT SPOT

Indoors, near an outlet.
Use handles to lift bin.

2

PEEL SEALS OFF CHARCOAL DRAWER

Remove top and bottom seals.
Slide drawer back into bin.

3


TAKE OUT THE BUCKET

Remove protective packaging
and set bucket aside.

4

PLUG IT IN

Attach power cord



Get the app to set up your bin

IN THE APP, YOU CAN ALSO...



Manage Dry & Grind cycles

Set when your bin runs a daily Dry & Grind cycle. Or manually start or stop a cycle.



Find a use for your grounds

Arrange a Food Grounds box pickup
or learn about other local options.



Check the food library

See what's okay — and not okay —
to put in your bin. We've thought of
(almost) everything.



Your bin communicates in lights



BUTTON



STATUS



LOCK




HEAT

STATUS ICON

Lets you know what your bin is up to.
Check the app for more info.



Running a cycle



Time to empty



Check the app



Jammed

BUTTON

Double press the button to manually
start or stop a Dry & Grind cycle.

LOCK ICON

Keep your bin locked when hot, always
locked, or always unlocked. Set your
preference in the app.

HEAT ICON

The heat icon will light up when the
bin is too hot to touch.